



SCNO-FDW-A | opticalCON - chassis connector cover

Dust cover assembly



- Ⓐ Mount steel cord onto the opticalCON chassis connector.

Dust cover handling



- Ⓑ Push the cover completely into the chassis until you feel a locking snap.

Applications example:



Cover application of chassis and cable connector (SCNO*X-A & SCNO-FDW-A).

- Ⓑ Mate cable connector and chassis connector cover to avoid contamination as long the connector is plugged.