HDMI Distribution Amplifier







USER MANUAL HIT-HDMI2K4K-14*PW

Package Contents-

- Distribution Amplifier
- 1x User Manual
- 1x Power Adapter DC 12V
- AC POWER cord (only HIT-HDMI2K4K-148PW)
- 2x Screws
- 4x Foot Pads

Anything missed, please contact with your vendor.

Introduction

Through the HDMI Distribution Amplifier, you can use one HDMI source such as DVD player to display / broadcast the identical image up to 8 projectors or HDTVs through HDMI ports.

HDMI Distribution Amplifier is ideal for:

- Test Bench Facilities
- Data Centers
- Help Desks


Features

- Supports 3D
- HDCP2.2/HDCP1.4 Compliant
- Compliant with the specification of HDMI
- Support high-resolution display up to 4Kx2K@60Hz(YCbCr 4:2:0 8/10/12/16-bit other 8-bit)
- EDID copy from OUT 1
- Cascade able to satisfy the demanded ports

Specifications


Function	**-142PW	**-144PW	**-148PW	
HDMI Input Connector (A-Type Female)	1			
HDMI Output Connector (A-Type Female)	2	4	8	
Max. Resolution	4x2K@60Hz			
Cable Distance (Device to Monitor)	10 m (Max.)			
Signal Type	Standard HDMI Signal			
Power Adapter (Min.)	DC 12	DC12V/5A		
Housing	Metal			
Weight	280g	476g	700g	
Dimensions (LxWxH)	150x80x25 mm	171x120x25 mm	240x120x25 mm	

Technical Specifications Input/Output Signal




Pin#	Signal	Pin#	Signal
1	TMDS Data 2+	11	TMDS Clock Shield
2	TMDS Data 2 Shield	12	TMDS Clock -
3	TMDS Data 2-	13	CEC
4	TMDS Data 1+	14	Reserved
	TWDO Data 11		(N.C. on device)
5	TMDS Data 1 Shield	15	SCL
6	TMDS Data 1-	16	SDA
7	TMDS Data 0+	17	DDC/CEC Ground
8	TMDS Data 0 Shield	18	+5 V Power
9	TMDS Data 0-	19	Hot Plug Detect
10	TMDS Clock+		

FRONT VIEW



- 1. "HDMI In" Port
- 2. "HDMI Out" Port

REAR VIEW



- 1. F/W Upgrade
- 2. Reset
- 3. Mode(must reset)

1110 110 (11111111111111111111111111111				
1	2	Mode		
OFF	OFF	1080P		
OFF	ON	Copy Out1		
ON	OFF	Reserved		
ON	ON	4K x 2K		

- 4. 1~2/1~4/1~8 Out port LED
- 5. HDCP LED
- 6. HDMI In LED
- 7. Power LED
- 8. DC 12V Input

Installation

- 1. Turn off the HDMI source and HDMI displays.
- Connect the HDMI male extension cable between the HDMI source and the "HDMI In" port of Distribution Amplifier.
- 3. Connect the HDMI male/female extension cables between the displays and the "HDMI Out" ports of Distribution Amplifier.
- 4. Connect the power cord and turn on the Distribution Amplifier.
- 5. Turn on the HDMI source and HDMI displays.

Note:


- Have to set ALL displays with the same resolution.
- We suggest the user connects the display from "HDMI Out 1" first because the Distribution Amplifier will simulate the EDID from "HDMI Out 1".
- We suggest the user connects the HDMI source to the Distribution Amplifier via1.8M cable for the better video quality.

Operation for cascade:

- 1. The function to display identical image on more displays, you have to attach another Distribution Amplifier.
- 2. Connect the HDMI male/female extension cable between the "HDMI Out 1" port of 1st level Distribution Amplifier and the "HDMI In" port of 2nd level Distribution Amplifier.

Note:

Even though you are allowed to cascade more Distribution Amplifiers to satisfy demanded ports, the image might become unstable if cascade too many levels of Distribution Amplifiers.



P.S.: The example of cascading the 2/4 and 8 ports Distribution Amplifier. Better yet, you can cascade more Distribution Amplifiers to satisfy demanded ports.